


# Winger Electronics SOLAROX® Mini Dimmer

Spannungsbereich / Voltage Range:	5...24V DC
Belastbarkeit / Load:	4A



## Installation

1. Verbinden Sie den LED Strip mit dem Controller. Achten Sie auf die richtige Polung.
2. Verbinden Sie den Controller mit dem passenden Netzteil. Der Eingangsspannungsbereich des Controllers beträgt 5-24V DC.
1. Connect LED strip with controller. Pay attention for polarity.
2. Connect controller with matching power supply. Input voltage range is 5-24V DC.

## Bedienung / Operation

1. **MODE** Taste: Schaltet in den dynamischen Betrieb. Mehrfaches Drücken wechselt zwischen 8 verschiedenen Programmen.
2. **SPEED/BRIGHT/OFF** Taste: Einstellung Geschwindigkeit im dynamischen Betrieb oder Verringerung Helligkeit im Dimmbetrieb. Längerer Druck >1s schaltet das Gerät aus.
3. **LIGHT/Brightness** Taste: Schaltet in den Dimmbetrieb. Jeder Druck erhöht die Helligkeit. Längerer Druck >1s schaltet auf 100% Helligkeit.
1. **MODE** key: Switch to dynamic mode. Press this key to switch among 8 dynamic modes.
2. **SPEED/BRIGHT/OFF** key: Adjust speed in dynamic mode or decrease brightness in static dimming mode. Press and hold >1sec turns power off.
3. **LIGHT/Brightness** key: Switch to static dimming mode. Press to increase brightness. Press and hold for 1 second to jump to 100% brightness.